

Chin protector

Mounting:

Remove the screws and rubber pads from the helmet using the inbus wrench provided. Place the chin guard on the helmet and attach using the screws and rubber washers that were previously removed, using the Allen wrench provided.

WARNING: The manufacturer is not responsible for improper installation or use of this product.

Dispose of the product in an environmentally friendly manner at the end of its useful life.

Made in the EU

MEFO SPORT CENTRUM s.r.o., Jinín 60, Strakonice 38601, www.mefo.cz